

de	Kurzanleitung Getränkekühler	2
en	Quick Start Guide Beverage cooler	4

Inbetriebnahme

Vorbereitung

- Das Gerät aus der Verpackung nehmen.
- Alle Verpackungsteile entfernen und aufbewahren.

Explosionsgefahr:

Das Gerät nicht in Betrieb nehmen, falls das System beschädigt wurde! In diesem Fall muss der Raum umgehend gut gelüftet und potenzielle Zündquellen entfernt werden.



Gerät aufstellen

- Das Gerät auf eine ebene, rutschfeste, wasserunempfindliche Unterlage in unmittelbarer Nähe zu einer Netzsteckdose stellen.
- Nur an den ausgewiesenen Griffen auf Vorder- und Rückseite hochheben.
- Der BEEZER® Getränkekühler darf nur in gut belüfteten Räumen betrieben werden.
- Die Belüftungsöffnungen nicht abdecken.
- Den Mindestabstand von ca. 5 cm zu den umliegenden Wänden einhalten.
- Netzkabel mit der Netzsteckdose verbinden.


Hinweis:

Lassen Sie das Gerät vor der ersten Inbetriebnahme mindestens 12 Stunden unbewegt stehen.

Betrieb


Einschalten und Vorkühlen

- Start-Taste gedrückt halten.
- Nach dem Einschalten:
Einmalige Vorkühlung von ca. 10 Minuten startet automatisch.
LED-Ring leuchtet türkis.
- Vorkühlvorgang abgeschlossen:
LED-Ring leuchtet weiß.



Weitere Informationen finden Sie in der beige packten Bedienungsanleitung oder auf unserer Homepage: www.ritterwerk.de/beezer

Download



Der BEEZER® Getränkekühler bietet zahlreiche Funktionen, die über die App gesteuert werden können. Hier die App herunterladen:




Verbindung

Dank der intuitiven Benutzeroberfläche des BEEZER® Getränkekühlers mit LED-Ring, Display und vier Knöpfen lassen sich die Einstellungen besonders benutzerfreundlich vornehmen.

BEEZER® Getränkekühler mit WLAN verbinden:




Durch gleichzeitiges Drücken der beiden unteren Tasten (Behältergrösse und Kühlstufe) wird der BEEZER® Getränkekühler mit dem WLAN verbunden. Die erfolgreiche Verbindung wird über das WLAN-Symbol auf dem Display angezeigt.



BEEZER® Getränkekühler mit BEEZER® Connect verbinden:

1. Öffnen Sie BEEZER® Connect.
2. Erstellen Sie ein persönliches Kundenkonto. Ohne Konto sind nicht alle Funktionen der App verfügbar.
3. Verbinden Sie Ihr Smartphone mit dem Heim-WLAN.
4. Aktivieren Sie Bluetooth® auf Ihrem Smartphone.
5. Öffnen Sie BEEZER® Connect, loggen Sie sich mit Ihrem Kundenkonto ein und wählen Sie auf der Startseite „Gerät hinzufügen (+)“.

App



Initial operation

First steps

- Take the unit out of the packaging.
- Remove and store all packaging materials.

Risk of explosion:

Do not operate the appliance if the system has been damaged!
If this is the case, the room must be well ventilated immediately and potential sources of ignition must be removed.



Device Set up

- Place the appliance on a level, non-slip, water-resistant surface in the immediate vicinity of a main power outlet.
- Only lift your BEEZER® using the designated handles on the front and rear of the unit.
- The BEEZER® may only be operated in well-ventilated spaces.
- Do not cover the ventilation ports.
- Maintain a minimum distance of approx. 5 cm from the surrounding walls.
- Connect the power cable to the wall socket.


Notice:

Before using the unit for the first time, leave it standing for at least 12 hours.

Operation


Switching on and pre-cooling

- Press and hold the start button.
- After switching on:
A one-time pre-cooling period of approx. 10 minutes starts automatically.
LED ring lights up turquoise.
- Pre-cooling process completed:
LED ring lights up white.



Further information can be found in the enclosed operating instructions or on our homepage:
www.ritterwerk.de/beezer

Download



The BEEZER® offers numerous functions that can be conveniently accessed via the app. Download the app here:




Connectivity

Thanks to the intuitive interface of the BEEZER® with its LED ring, display and four buttons, the settings are particularly user-friendly..

Connecting the BEEZER® to Wi-Fi:

Press the two lower buttons (container size and cooling level) simultaneously to connect the BEEZER® to Wi-Fi. The successful connection is indicated when the Wi-Fi symbol appears on the display.



Connecting the BEEZER® with BEEZER® Connect:

1. Open the BEEZER® Connect.
2. Create a personal customer account. Some app functions are not available without an account.
3. Connect your smartphone to the home Wi-Fi.
4. Activate Bluetooth® on your smartphone.
5. Open the BEEZER® Connect, log in with your customer account and select 'Add device (+)' on the homepage.

App

